

LE KLINT

MADE IN ODENSE, DENMARK SINCE 1943

Egestubben 13-17 • 5270 Odense N
www.leklint.com • leklint@leklint.dk



KAARE KLINT LEGACY

LE KLINT

Instruktion
Instructions Manual

Vejledning for Model LK 101KKL

INDHOLD

Foldet skærm, ophæng med messingring. Baldakin og loftskrog til ophængning.

VEDLIGEhold

Messingringen er lakeret og kan gøres ren med en fugtig klud.

Skærmen kan rengøres med en børste eller en blød fugtig klud, såfremt der kommer pletter på den.

LYS

Vi anbefaler at bruge en LED pære.

Model 101: E14, max. 10 W, anbefalet 470 lumen

MONTAGE

1. Pak alle dele ud så de er klar til montage.
2. Afmonter messingringen fra lampeskærmen, ved at presse plisséerne sammen i toppen og krænge ringen ud over dem.
3. Træk messingringen op over fatningen og monter lyskilden.
4. Nu trækkes skærmen ud over lyskilden og helt op over plastikkeglen der sidder over fatningen.
5. Pres plisséerne sammen igen og træk messingringen tilbage omkring halsen på lampeskærmen.
6. Skærmen kan nu skubbes ned over plastikkeglen over fatningen. Det er vigtigt at skubbe skærmen ned på plads som på billedet, hvis man holder fast rundt om halsen på skærmen mens den skubbes på plads kan det være svært at få skærmen på plads.

Lampen kan hænges op med loftskrog og/eller baldakinen der medfølger.

Instructions for Model LK 10KKL

CONTENTS

Folded shade, hang-up with brass ring. Canopy and ceiling hook for suspension.

MAINTENANCE

The brass ring is varnished and can be cleaned with a damp cloth.

The shade can be cleaned with a brush or a soft damp cloth if it gets stained.

LIGHT

We recommend using an LED bulb.

Model 101: E14, max. 10 W, recommended 470 lumen

ASSEMBLY

1. Unpack all parts so that they are ready for assembly.
2. Remove the brass ring from the lampshade by pressing the pleats together at the top and tilting the ring out over them.
3. Pull the brass ring up over the socket and install the light source.
4. Now pull the shade out over the light source and all the way up over the plastic cone that sits above the socket.
5. Press the pleats together again and pull the brass ring back around the neck of the lampshade.
6. The shade can now be pushed down over the plastic cone above the socket. It is important to push the shade down into place as in the picture, if you hold onto the neck of the shade while pushing it into place it may be difficult to get the shade into place.

The lamp can be hung with the ceiling hook and/or the canopy that is included.

